

S-9/S-10 Tower with Redundant Power Supply




Remove two posts (circled in green on the image) inside the case if necessary.



Remove the power supply bracket.



Install redundant power supply's housing and secure it with screws



Install two modules.



Finishing look.